



2293  
+  
50

2293  
+  
50

2293  
+  
00

2293  
+  
00

2292  
+  
50

2292  
+  
50

AREA  
EXC. EMB.

VOLUME  
EXC. EMB.

40	23	PHASE 1
202	60	PHASE 2
23	16	PHASE 3

PHASE 1	113	22
PHASE 2	672	70
PHASE 3	22	64

83	1	PHASE 1
524	16	PHASE 2
1	44	PHASE 3

PHASE 1	307	1
PHASE 2	1070	17
PHASE 3	1	240

249	0	PHASE 1
632	2	PHASE 2
0	181	PHASE 3

PHASE 1	325	2
PHASE 2	1153	3
PHASE 3	2	256