



2435  
+  
50

AREA	EXC.	EMB.	PHASE
37	0	0	PHASE 1
41	31	0	PHASE 2
0	0	37	PHASE 3

VOLUME	EXC.	EMB.	PHASE
82	0	0	PHASE 1
70	36	0	PHASE 2
0	0	94	PHASE 3

2435  
+  
50

2435  
+  
00

AREA	EXC.	EMB.	PHASE
51	0	0	PHASE 1
35	8	0	PHASE 2
0	0	51	PHASE 3

VOLUME	EXC.	EMB.	PHASE
111	0	0	PHASE 1
74	8	0	PHASE 2
0	0	127	PHASE 3

2435  
+  
00

2434  
+  
50

AREA	EXC.	EMB.	PHASE
68	0	0	PHASE 1
45	0	0	PHASE 2
0	0	68	PHASE 3

VOLUME	EXC.	EMB.	PHASE
139	0	0	PHASE 1
42	0	0	PHASE 2
0	0	160	PHASE 3

2434  
+  
50

**STA. 2434+50  
END INCIDENTAL CONSTRUCTION &  
BEGIN PROJECT**